






















MAZDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
1	F8, FE	JT180001 F801-10-512 FE01-10-512	
2	F8, FE	JT180002	
3	F8, FE	JT180003 F801-10-502	
4	B3, B6	JT180004	
5	B3, B6	JT180005	
6	B3, B6	JT180006 B630-10-503	
7	B3, B6	JT180007 8FDA-6020AA	








MAZDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
8	F2, FE	JT180008 FE1H-10-512 F201-10-512	
9	F2, FE	JT180009 F8B2-10-512 FE1H-10-502A	
10	F2, FE	JT180010 FE1H-10-543C FE1H-10-546	
11	F2, FE	JT180011 FE1H-10-544	
12	F2, FE	JT180012 FE1H-10-545	
13	FE	JT180013 FE3N-10-502 F8B2-10-512 JT180009	
14	F8, F2SA	JT180014 F850-10-501	




MAZDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
15	F8	JT180015	
16	F8	JT180016	
17	B3, B6	JT180017 B630-10-502	
18	R2, RF	JT180018	
19	R2, RF	JT180019	
20	R2, RF	JT180020	
21	R2, RF	JT180021	

MAZDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
22	R2, RF	JT180022	
23	R2, RF	JT180023	
24	R2, RF	JT180024	
25	KJ	JT180031	
26	KJ	JT180032	
27	KJ	JT180033	
28	JE	JT180025 JE15-10-502	

MAZDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
29	JE	JT180027 JE15-10-512	
30	JE	JT180028 JE15-10-503	
31	JE	JT180029 JE13-11318	
32	JE	JT180030	