





















HONDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
1	B16A, B16A1, B16A2, B16, B18C, B18C5	JT100001 11925-P30-000 JT100002 11926-PR3-000	
2	D15B, D15BB, D17A, D14Z6, D17A5, D17Z3	JT100005 11831-PLC-000 JT100004 11832-PLM-000 JT100003 11833-PLM-000	
3	D15B2, D16Z1, D16Z2, D16Z6, D16Z7	JT100006 JT100007 JT100009 JT100008 JT100010	
4	D13B, D15B, B15B1, D15B2, D15B6 16V	JT100011 11831-PM3-000 JT100012 11832-PM3-000 JT100013 11833-PM3-000	
5	D13B, D15B, B15B1, D15B2, D15B6 12V	JT100011 11831-PM3-000 JT100013 11833-PM3-000 JT100014 11831-PM6-000	
6	ZC1, ZC, ZV, D16A1, D16A2, D16A8	JT100015 JT100016 JT100017	
7	EN, EN4	JT100019 11821-PA1-010 JT100018 11831-PA1-010	

HONDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
8	EK1, EK2, EP1, EL, ER	JT100020 11831-PB2-000 11831-689-000 JT100021 11109-689-000	
9	B18A, B20A, B20A5, B21A1	JT100023 JT100022 JT100024 JT100025 JT100026	
10	EB1, EB2, EB3	JT100029 11831-634-000 JT100027 11821-634-000	
11	A20A, ES-1, ET2, ES, EY	JT100030 11831-PC6-000	
12	C30A		
13	C32A		

HONDA

NO.	CAR INFO.	PART NO.	TIMING COVER GASKET
14	F18A, F20A, F20A, F22A, F18B, F20B, F22B	JT100049 JT100055 JT100051 JT100052 JT100053 JT100050 JT100054	
15	EV2, ZA1, ZA2, EW2, EV1, EW1	JT100056 11831-PE0-000 JT100057 11821-PE0-000 JT100012	
16	B20A1, B20A5	JT100058	
17	EJ, EJ1	JT100059 11831-PA0-000 11831-PA5-000	
18	B16A, B18A1, B18B, B18B1, B18C, B20B4, B20Z2	JT100061 JT100062	
19	ED, EF	JT100063 11831-657-000	
20	ER	JT100064 11831-PC0-000	
21	D16Y5	JT100065	